

# RISE

UNDERFLOOR HEATING

## WI-FI SMART THERMOSTAT

For Underfloor Heating Systems



INSTALLATION MANUAL



# HEATING HOMES FOR THE FUTURE

OUR AMBITION IS SIMPLE.  
TO PREPARE HOMES FOR THE FUTURE

Rise underfloor heating solutions are no nonsense and uncomplicated. We simply use the best technologies, premium materials and rigorously test our products to give you peace of mind when it comes to your home. Underfloor heating is an essential, our trusted products are easy to fit and affordable helping you to prepare your home for the future.

## HERE'S WHAT YOU NEED TO KNOW

Wi-Fi Connectivity

---

Smart Schedule

---

Auto Frost  
Protection

Energy Saving

---

Holiday Mode

---

Boost Button


App Control

---

Geolocation

---

Temperature &  
Humidity Sensor

A modern living room featuring a fireplace with a wood-grain base and a glass front. A wooden chair with a white fur seat and backrest is on the left. A light-colored corduroy sofa is on the right. The floor is made of large, light-colored wood-look tiles. The fireplace has a fire burning inside. A potted plant is visible in the background.

# WELCOME

Our Wi-Fi touch screen thermostat makes smart high-performance heating easier than ever. This guide tells you everything you need to know. Please remember to touch the screen to get all of the icons to show!



# CONTENTS

6	Main display	25	Screen saver
9	Introduction	26	Lock screen
10	Mode selection	27	Network settings
11	Pair app to thermostat	28	Feature settings
12	App operation Home/away	32	System information Reset to factory settings
15	Hold function	33	Installation
16	Holiday	35	Dimensions
17	Schedule	36	Wiring diagram
20	Configuration settings	37	Mode 2 time clock
23	Language Clock setting	38	Boost mode
24	Display brightness	39	Technical specification

# MAIN DISPLAY



- 1 Wi-Fi indicator - the Wi-Fi indicator display will not be flashing when connected to the Wi-Fi network.
- 2 Weekday indicator.
- 3 Display "heating" flame to indicate floor heating up.
- 4 °C or °F display.
- 5 Clock indicator.
- 6 Away/home: means thermostat is maintaining a lower temperature to give frost protection. Allows also a user preset set-back temperature while away from the house.
- 7 Room temperature display.
- 8 Schedule: programmable operation.
- 9 Increase the temperature setting.
- 10 Setting temperature display.

- 11 Lower the temperature setting.
- 12 Configuration menu button.
- 13 Holiday: displayed when thermostat is in holiday mode.
- 14 Hold temperature.

# INTRODUCTION

## **Benefits of programmable thermostats**

A programmable thermostat helps make it easy for you to save by offering six\* pre-programmed settings to regulate your temperature for both summer and winter.

The pre-programmed settings that come with programmable thermostats are intended to deliver savings without sacrificing comfort. Depending on your schedule, you can see significant savings by sticking with these settings or adjust them as appropriate.

The key is to establish a program that automatically reduces heating and cooling in your home as required.



**\*PLEASE NOTE ONLY MORNING AND EVENING  
SETTINGS CAN BE ALTERED VIA THE APP.**

## MODE SELECTION

The Wi-Fi Smart Thermostat comes with two modes for the user to select, thermostat mode and timer mode.

Thermostat mode (fully programmable mode) - allows time and temperature settings to be made. This allows the thermostat to be programmed to a specific temperature during a specific time.

Timer mode - allows for the time only setting to switch on or off as desired. This mode ignores any temperature.

To change between thermostat and timer modes, follow these steps (use your finger as the screen is touch sensitive).

-  Press the  icon to enter configuration menu.
-  Using the  icon, scroll across to "feature setting" and press to select it.
-  Use the  icon, scroll across again to "work mode" and press to select it
-  Select "heating mode" or "timer mode".  
The thermostat will re-set and enter the desired mode.

# PAIR APP TO THERMOSTAT

## Pairing the Thermostat with the App



THE ROUTER NEEDS TO BE 2.4G BAND ONLY

Download the free Wi-Fi Thermostat app from the apple store or the google play store by searching "MyComfort House".



Time	Temp	Temp	Temp
WAKE	08:00	22°C	
LEAVE	9:30	32°C	
RETURN	16:30	22°C	
SLEEP	23:00	30°C	

Temp	Temp	Temp
00	00	0°C
01	01	1°C
02	02	2°C
03	03	3°C
04	04	4°C
05	05	5°C
06	06	6°C
07	07	7°C
08	08	8°C
09	09	9°C
10	10	10°C
11	11	11°C
12	12	12°C
13	13	13°C
14	14	14°C
15	15	15°C
16	16	16°C
17	17	17°C
18	18	18°C
19	19	19°C
20	20	20°C
21	21	21°C
22	22	22°C
23	23	23°C
24	24	24°C

## APP OPERATION 01-07



PLEASE ENABLE THE "LOCATION" TO MYHOUSE APP  
IN YOUR MOBILE SETTINGS BEFORE ANY OPERATION,  
OR ELSE THE GEO DISTANCE WILL NOT CONNECT.

1 Open  MyComfort House and register your account.

2 Log into your account.

3 Press the  icon on app home screen.

Press "location name" to add the location, for example home/office etc.

Press  icon to confirm the property.

Press  icon to go back to the main screen.

4 Press the  icon on the app home screen to enter the "add device" screen.

5 Select "smart config" option on "add device" screen.

Press the bottom button "add device location" to enter Wi-Fi configuration.

- 6 Enter the Wi-Fi password (please ensure the router password is correct).

Press the “next” button on the bottom to enter “pairing device” screen.

- 7 Waiting for thermostat feedback on the “pairing device” screen, the count down is 120 seconds, if pairing failed, please check the Wi-Fi password and pair again.

## Thermostat Operation

- 8 On the home screen, press the  icon and enter “network settings”.

- 9 Find “pair to app (smart config)” and press it.

- 10 Wait for the devices to pair (this may take several minutes to activate).

- 11 The app will display “connected to the Wi-Fi” and will display “app matching success” on the controller.

# OPERATION OF HOME SCREEN



## HOME/AWAY

---

- 1 When the user switches the thermostat to “away mode”, the thermostat will still protect itself from frost after the defrost temperature is set. When the temperature is lower than the set defrost temperature, heating will be turned on, meanwhile, the flame icon will be displayed on the thermostat.
- 2 The thermostat automatically enters the defrost mode when “away mode” is selected.



## HOLD

---

The “hold” function allows you to maintain or hold a temperature and override any pre-set programs that have been created. This temperature will remain until the end of the “hold period” and revert back to any pre-set programs you have created.

- 1 Press “hold” and enter the setting screen.
- 2 Press the first column of “hold temp”, use the  icon to set the desired temperature. (Temperature range 5°C-35°C).
- 3 Press the second/third columns of hour/minute, use the  icon to set the desired “hold time”.
- 4 Press the  icon to save and return to main display, or press “cancel” to delete the setting.

You will see the “hold left: \*\*:\*\*” indication is displayed on screen. The time will count down the set duration and then revert to the normal program.



## HOLIDAY

---

The Wi-Fi Thermostat will maintain this temperature for the duration of the holiday and will then automatically return to the program mode on your return.

-  Press “holiday” to enter setting screen.
-  Press the column of years/month/day, use the  icon to set year/month/day values under holiday start.
-  Press the column of years/month/day, use the  icon to set the year/month/day values under holiday end.
-  Press the  icon to save and return to main display. This setting will be displayed on the home screen as “holiday until \*\*/\*\* \*\*:\*\*” or press “cancel” to delete the setting.



## SCHEDULE

---

- 1 Press the  icon to enter feature settings.
- 2 Select the “schedule” option to enter the settings screen. Select one of the four options: weekday/weekend, 7 days, 24 hours, none.
- 3 For example, setting the program mode to 7 days.
- 4 Press the  icon in the front of 7 days, and it will turn to .
- 5 Press the  icon to save and return to main display.
- 6 Press the “schedule” on the main display to enter “edit” screen.
- 7 On the edit page, from Monday to Sunday can be selected to edit.
- 8 Press “Monday” and enter Monday's setting screen.



There are four time periods that can be selected: morning/day/evening/night.

(each time periods has  options).

In the program of Monday:



Morning 

Press the first column of “time” and use the  icon to set desired “hour”.

Press the second column of “time” use the  icon to set desired minute.

For example: the setting time is 04 (hour): 00 (minute).

Press the third column of “temperature” and use the  icon to set desired temperature.

For example: the setting temperature is 27°C.



Day 

The same as program morning procedures.

For example: the setting time is 10 (hour): 40 (minute)

For example: the setting temperature is 24°C.

**3** Evening 

The same as program morning procedures.

For example: the setting time is **12 (hour): 30 (minute)**.

For example: the setting temperature is **26°C**.

**4** Night 

The same as program morning procedures.

For example: the setting time is **24 (hour): 00 (minute)**

For example: the setting temperature is **28°C**.

### **Four time periods**

1. 04:00 - 10:40: during this time the temperature will remain at 27°C
2. 10:40 - 12:30: during this time the temperature will remain at 24°C
3. 12:30 - 24:00: during this time the temperature will remain at 26°C
4. 24:00 - 04:00: during this time the temperature will remain at 28°C

## CONFIGURATION SETTINGS

Press the  icon in home screen and enter configuration menu.

Language	English, French, German, Spanish, Polish, Czech, Russian, Slovenian
Date & time	<b>01)</b> Time zone <b>02)</b> Date & time <b>03)</b> Daylight saving time (DST)
Backlight	Ambient light dimming
Standby screen	Standby screen <b>01)</b> Time: 3 min, 10min, just night <b>02)</b> Type: clock, default, off screen
Screen lock	If you forget your 4 digit pin, you will find the "Master Pin" on Page 26 of this brochure
Hold temperature	Hold time Hold setpoint

History	<ul style="list-style-type: none"><li>01) Running time chart</li><li>02) Temperature chart</li><li>03) Humidity chart</li></ul>
Network settings	<ul style="list-style-type: none"><li>01) Wi-Fi setup</li><li>02) Pair to app</li><li>03) QR code</li><li>04) Mac address</li></ul>
Feature settings	<ul style="list-style-type: none"><li>01) Temperature format</li><li>02) Temperature limit</li><li>03) Switch differential</li><li>04) Output delay</li><li>05) Away temperature</li><li>06) Defrost: enable/disable</li><li>07) Sensor option:<ul style="list-style-type: none"><li>Built-in sensor</li><li>Remote air sensor</li><li>Floor sensor only</li><li>Built-in &amp; floor sensor</li><li>Remote air &amp; floor sensor</li></ul></li><li>08) Humidity sensor calibration</li></ul>

Feature settings	<p>09) Energy tariff Set energy usage per hour Set unit cost per kw/h</p> <p>10) Open window function Disable/enable this feature</p> <p>11) Floor temperature limit Set floor temp. range from 20°C to 60°C</p> <p>12) Optimum start Disable/enable this feature</p> <p>13) Work mode selection: Thermostat Timer</p>
Schedule	<p>Weekday/weekend 7 days 24 hours None</p>
System information	Version number, QR code
Reset to factory settings	Delete all settings to factory default configuration



## LANGUAGE

---

User can set a different language for the Wi-Fi Smart Thermostat, there are 8 languages in total.

Press the “settings” icon. Select “language” icon. Using the “scrolling up or down” icon to select one of the 8 languages.



## CLOCK SETTING

---

To set the clock, follow these steps.

-  Press the  icon and enter feature settings.
-  Press the “clock setting” and enter setting screen.
-  Press the column of day/month/year, use the  icon to set the day/month/year.
-  Press the column of “time”, use the  icon to set hours/minutes.
-  Press the  icon to save and return to main display.



## DISPLAY BRIGHTNESS

---

- 1 Press the  icon and enter feature settings.
- 2 Press “backlight” selection and enter backlight setting.
- 3 Ambient light dimming is in  mode:  
automatically adjusts the backlight brightness.
- 4 Ambient light dimming is in  mode:  
manually adjust the backlight brightness.
- 5 Use the  icon to adjust to the desired brightness.  
Press the  icon to save and return to main display.



## SCREEN SAVER

---

- 1 Press the  icon to enter feature settings.
- 2 Press “standby screen” to enter setting screen.
- 3 There are four selection (3min, 10min, just night, never) to control the standby screen time.
- 4 For example, setting the standby time for 10 minutes. Press the  icon in the front of “10 min” and it will turn to .
- 5 Press the  icon to save and return to main screen.



## LOCK SCREEN

---



Press the  icon to enter feature settings.



Press “screen lock” to enter setting screen.  
Lock pin  options.



For example, setting the lock pin to 5209.

Press the first column, use the  icon to set to 5.

Press the second column, use the  icon to set to 2.

Press the third column, use the  icon to set to 0.

Press the fourth column, use the  icon to set to 9.



Press the  icon to save and return to main screen.



NOTE

To unlock the Wi-Fi Thermostat press the display and add your four digit pin number that you previously set.

MASTER PIN IS 8657



## NETWORK SETTINGS

---



Press the  icon to enter feature settings.



Press “network settings” and enter setting screen. You can select one Wi-Fi network and set the Wi-Fi password in 01- Wi-Fi setup screen.

To use the “smart config function” pair thermostat to app, please press 02- pairing to app (smart config).

If the thermostat model has RS485 feature you can set the Modbus Address by selecting 05-Modbus Address.



## FEATURE SETTINGS

---

1

### **Temperature format:**

Select between °C and °F.

2

### **Temperature limit:**

Set the temperature setting limitation range.

3

### **Switch differential:**

Set a parameter for when the heating function is triggered as the room temperature falls below the target temperature.

For example, if the switch differential is set to 0.5, the heating will trigger once the room temperature falls 0.5 degrees below than the target temperature.

4

### **Output delay:**

To prevent rapid switching, an output delay can be entered. This can be set from 0-15 minutes (the default is 00, meaning no delay). This function helps to prevent system “short-cycling”.

5

**Away temperature:**

Set the away temperature.

6

**Defrost: enable/disable:**

The thermostat will automatically enter the defrost mode when the room temperature drops below the defrost temperature.

7

**Sensor option:**

There are five sensor options - selecting each will enter a calibration screen for that setting:

- Built in sensor (default).
- Remote air sensor.
- Floor sensor only.
- Built-in floor sensor.
- Remote air & floor sensor.

8

**Humidity calibration:**

Calibrate the humidity.

9

**Energy tariff:**

Set the energy usage, kw/h and £/kw so user could check the energy or cost in the history chart of home screen.

10

**Open window function:**

This option allows you to enable the “open window” function. The thermostat can detect an open window by registering a rapid drop in temperature. With the function enabled, the thermostat shuts off the heating for 30 minutes if an open window is detected.

11

**Floor temperature limit:**

Set the floor sensor limitation.

12

**Optimum start:**

Wi-Fi Smart Thermostat makes use of the rate of change previously figured out to further calculate how far ahead of time the heating function should be triggered, in order to maximise the energy conservation, as well as be able to make the house warm and comfortable at specific time. For example, if the rate of change is 20, it will take 20 minutes to realise the rise of 1 degree. Then the Wi-Fi Smart Thermostat can further figure out how far ahead of time the heating function has to be triggered to make the room comfortable on the premise of energy saving.

13

**Work mode selection:**

Change between thermostat and timer modes.



## SCHEDULE

---

Wi-Fi Smart Thermostat provides three programming modes and can also be set to a non-programmable thermostat. Weekday / weekend (5 + 2) programming allows you to edit the 4 time periods for the weekdays and 4 time periods for Saturday & Sunday.

7-day programming mode can be programmed each day with 6 time periods.

24 hours mode-every day can be edited with 4 time periods.



## HOLD TEMPERATURE

---

Set the hold temperature and time, this is same as the hold function in the home screen.



## SYSTEM INFORMATION

---

- 1 Press the  icon to enter feature settings.
- 2 Press “system information” to enter screen, this will show the version number.
- 3 Press the icon  to exit.



## RESET TO FACTORY SETTINGS

---

- 1 Press the  icon to enter feature settings.
- 2 Press  to enter setting screen.
- 3 Press “reset” to factory settings.
- 4 Press the  icon to exit.



**WARNING: RESET WILL MAKE YOU LOSE THE CURRENT SETTINGS AND RETURN TO THE FACTORY SETTINGS.**



## INSTALLATION

---

Install the thermostat at the eye level or as required by your local building regulations. Please read the instructions in order to better understand our products. Do not install in areas close to a heat source, which will affect its function. This thermostat is designed to be flush mounted and requires a 35mm recessed box in the wall.

### STEP 1

Using a flat-blade screwdriver, loosen the screw from the bottom of the thermostat, and then separate the front half from the backplate.

### STEP 2

First place the front panel of the thermostat in a safe place. Then follow the wiring diagram on page 36 of this manual for connecting terminals.


### STEP 3

Screw the thermostat backplate into the mounting box in the wall using the correct screws (do not over-tighten).


### STEP 4

Refit the thermostat front panel onto the thermostat backplate fastening, and then gently re-tighten the retaining screw.

# OUTLINE DIMENSION



## WIRING DIAGRAM



# MODE 2-TIME CLOCK

## SETTING THE TIME CLOCK

---

To program the clock times, when in time clock mode, follow these steps.

**1** Press “schedule” on the main screen.

**2** Press weekday and enter setting screen.

Four time periods can be selected to program (each period has on/off icon  options).

**3** Press the “hour” of the on time and use the icons  to adjust to the desired hour.

**4** Press the “minute” of the on time and use the icons  to adjust to the desired minutes.

**5** Press the “hour” of the off time and use the icons  to adjust to the desired hour.

- 6 Press the “minute” of the off time and use the  icons to adjust to the desired minutes.

Repeat these steps to set all periods.

## BOOST MODE

---

The boost function allows you to override the thermostat outside of the programmed times and manually turn on for your desired time period. This function overrides the pre-set time settings for a desired length of time. This can be to override on or override off. To activate the boost, follow these steps.

- 1 Press “boost” icon.
- 2 Select your desired “boost” mode on or off.
- 3 Press “hour” and use the  icons to set the desired hours.
- 4 Press “minute” and use the  icons to set the desired minutes icon and press cancel.

-  Press the  icon to save and return to the main screen.
-  The “boost” time remaining will be displayed at the top of the screen.
-  To cancel “boost”, press “boost” main icon and press cancel.

## TECHNICAL SPECIFICATION

**Power supply:** 230vac, 50-60Hz, 16A

**Setting temp range:** 5-35°C temp accuracy:  $\pm 1^{\circ}\text{C}$

**Power consumption:** 1w

**Floor temperature limit:** 20-45°C

**Max switch current:** 3a/16a (optional)

**LCD screen size:** 3.5 inch

**Touch:** capacitive touch

**Dimension:** 103 x 86 x 42.5mm (L x W x D)

**Grade of protection:** IP20



Your Wi-Fi Smart Thermostat comes with a 5-year warranty from date of purchase. If you have any problems installing or programming your thermostat, please contact our dedicated technical support team who will be happy to help you.

Freephone helpline: **0800 246 5963**

Email: **[enquiries@riseheating.co.uk](mailto:enquiries@riseheating.co.uk)**